

ELECTRIC RICE COOKER

Instruction manual



Dear consumer, Please read these instructions carefully before use in order to avoid damage due to incorrect use and to better understand the functions of this product. Please pay particular attention to the safety guide.

If you pass the device on to a third party, these Operating Instructions must also be handed over.

Please keep them for future references.



IMPORTANT SAFEGUARDS

- Please read these instructions carefully before use.
- Keep present instructions for future references.
- Check that your mains voltage corresponds to that stated on the appliance.
- Only use the appliance for domestic purposes and household or similar applications such as:
 - staff kitchen areas, in shops, offices and other working environments;
 - By clients in hotels, motels and other residential type environments;
 - Environment type like :
 - Farm Houses • Bed and Breakfast.
- Only use the appliance in the way indicated in these instructions.
- Never use this unit near bathtub, shower, wash-hand basins or other containers with water.
- Never use this apparatus near water projections.
- Never use this apparatus with the wet hands.
- If, unfortunately the apparatus is wet, immediately withdraw the cord of the socket-outlet.
- Inform potential users of these instructions.
- Never leave the appliance unsupervised when in use.
- The appliance must be used only for its intended purpose. No responsibility can be taken for any possible damage caused by incorrect use or improper handling.
- Children and persons with disabilities are not always aware of the danger posed by the use of appliances.
- This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.

- Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Keep the appliance and its cord out of reach of children aged less than 8 years.
- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- In order to ensure your children's safety, please keep all packaging (plastic bags, boxes, polystyrene etc.) out of their reach.
- Caution ! Do not allow small children to play with the foil :
THERE IS A DANGER OF SUFFOCATION !
- From time to time check the cord for damages. Never use the appliance if cord or appliance shows any signs of damage.
- Never immerse the appliance in water or any other liquid for any reason whatsoever.
- Never place it into the dishwasher.
- Never use the appliance near hot surfaces.
- Do not operate the appliance with a damaged cord or plug, or after the appliance has been damaged in any manner.
- If the supply cord or appliance is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Disconnect the power source cable before any operation of cleaning of maintenance and accessories assembly.
- Never use the appliance outside and always place it in a dry environment.
- Never use accessories, which are not recommended by the producer. They could constitute a danger to the user and risk to damage the appliance.


- ❑ Never use any other connector than the one provided.
- ❑ Never move the appliance by pulling the cord. Make sure the cord cannot get caught in any way.
- ❑ Never wind the cord around the appliance and do not bend it
- ❑ Ensure that the power cord does not come into contact with hot parts of this unit.
- ❑ Make sure the appliance has cooled down before cleaning and storing it.
- ❑ The temperature of accessible surfaces may be very high when the appliance is operating. Never touch these parts, of apparatus, to avoid burning itself.
- ❑ Make sure the appliance never comes into contact with flammable materials, such as curtains, cloth, etc...& the power cord and plug do not come in contact with water.
- ❑ Before cleaning, always unplug the appliance from the power supply and let it cool down.
- ❑ This appliance is not intended to be operated by means of an external timer or separate remote-control system.
- ❑ Always place the unit on a flat surface. Ensure, also, not to cover the device and not to put anything on it.
- ❑ Always remove the plug from the wall socket when the appliance is not in use.
- ❑ When using an extension lead always make sure that the entire cable is unwound from the reel. Use solely CE approved extension leads. Input power must be at least 16A, 250V, 3000W.
- ❑ Incorrect operation and improper use can damage the appliance and cause injury to the user.
- ❑ This device, designed for home use, complies with standards relating to this type of product.
- ❑ The appliance must be used and rested on a table or flat & stable surface.

- The item must not be left unattended when it is connected to main supply.
- The item is not to be used, if it has been dropped or if there are visible signs of damage or if it is leaking.
- Regarding the instructions for cleaning, thanks to refer to the below paragraph of the manual.
- This appliance is only intended for household use.
- The heating element surface is subject to residual heat after use.
- Warning: avoid spillage on the connector.
- Warning: potential injury from misuse.

(*) **Competent qualified person** : after sales department of the producer or importer or any person who is qualified, approved and competent to perform this

GENERAL INFORMATION


The symbol "OPEN BOOK" means a recommendation to read important things contained in the record.



The symbol "BIN" crossed out, abbreviation WEEE (Waste of Electrical and Electronic Equipment) means that at the end of life, it should not be discarded with household waste, but filed to the sorting of the locality. Waste recovery can help preserve our environment.



The symbol "STEAM" warns the user that steam can escape from the unit and to take all necessary precautions. (Risk of burns)




The symbol "CE" is the guarantee of compliance with harmonized European standards, voluntary, reflecting



the essential requirements into technical specifications. These standards are not mandatory but are guarantees of compliance with essential requirements.

The symbol "GLASS / FORK" means that the device is compatible and can come into contact with foodstuffs.



The symbol ROHS (Restriction of use of some Hazardous Substances) on the Environmental Protection, certifies that for each of the five hazardous substances • Lead • Mercury • (hexavalent) chromium • products for protection against flames PBB and PBDE, the peak concentration is equal to or less than 0.1% of the weight of homogeneous material, and 0.01% for the 6th • cadmium.

The symbol "TRIMAN" indicates that the consumer is invited to dispose the product as part of a separate collection (eg recycling bin, waste, voluntary intake point).



For more information : <http://www.quefairedemesdechets.fr>

CLEANING AND MAINTENANCE

- Before cleaning the steamer, always unplug the appliance and allow it to cool.
- Remove the cover and the internal container of the cooker.
- Parts (removable), in contact with food such as: container, lid, Bowl, Fork, Spatula etc. ; can be cleaned in hot water with a sponge and washing up liquid or washed in the dishwasher.
- Clean the outside of your cooker when necessary with a damp sponge or cloth or with a mild detergent. Never use an abrasive cleaner.
- Do not use any metal tools or iron wool on the outside of the appliance or on the cooking container, as this may damage them.
- Never immerse the device in water or any other liquid!
- To clean the plate and the electrical resistance use iron wool to polish or to remove residues. Clean with a damp cloth, dry completely before using the device again.
- Keep the heating plate and the resistance out of contact with any object, if not, the appliance may no longer function properly.
- Any residue of vinegar or salt can cause your internal container to erode. Clean it thoroughly after each use.
- ALL REPAIRS MUST BE PERFORMED BY AN AUTHORIZED SERVICE.

TO KNOW ITS UNIT

1. Lugs for hanging the cover
2. Lid handle
3. Metal cover
4. Non-stick container
5. Carry handles
6. Control panel
7. Non-slip feet



Lugs and Handles

The handles of the appliance are perforated to receive the lugs on **the handle of the cover** and hold it **opened**, vertically, so that, rice can be served more easily.



FIRST USE

The rice cooker provides a simple method of perfect rice cooking.

The warm function automatically keeps the rice warm, fluffy and ready to serve for up to 5 hours.

Many other foods can be cooked in the rice cooker such as vegetables, fish, meat, seafood and poultry.

Before first use, remove the unit and all accessories carefully.


Clean with soap and water, bowls and all accessories. Rinse and dry thoroughly. Clean the outside and inside of the machine cabinet with a damp cloth and wipe dry.

USE

- Unroll the power cord completely.

- Check that the tension in force in the country where you are, corresponds to that indicated on the apparatus.
- Connect the apparatus in a correct socket-outlet, (and connected to the ground if the unit is Class I), to avoid any danger.
- Disconnect the power cable from the mains before any maintenance cleaning and fitting of accessories.
- Always place the appliance on a horizontal table or flat surface.
- Never modify the device.

- Set the ON / OFF button (1A) on " I " position.
- The pilot light will light up.
- At the end of cooking, the cooker will automatically move to "Keep Warm" function.



Notes : Always place the inner container in the cooker before use.

The cooker will only work if the internal container is correctly in place.

Always set the "On / Off" switch to Off after use Otherwise, the cooker will be powered. (if it stays connected).

Always place the lid on the appliance during cooking.

- Leave the lid in place after serving to prevent the rice from drying out.
- To reheat cold rice, add cold water, a quarter of the measure per measure of rice, stir, then place the button on "Cooking". After a few minutes, set the selector to "Keep warm" or switch off the appliance.

Note : For easy use, the internal container is graduated to put the adequate amount

of water. A measuring cup is provided.

Using the measuring cup provided, measure and place the rice in the internal container. (One full measurement equals one cup).


Examples of how much water to add to the container.

<u>Raw Rice</u>	<u>Water</u>
2 cups	2 - 2½ cups
4 cups	4 - 4½ cups
6 cups	6 - 6½ cups
8 cups	8 - 8½ cups
10 cups	10 - 10½ cups
12 cups	12 - 12½ cups

14 cups
15 cups
23 cups

14 - 14½ cups
15 - 15½ cups
23 - 23½ cups

CAUTION



BEFORE STARTING TO COOK, CLEAN THE INTERIOR AND EXTERIOR OF THE TINNER POT. INSERT AND ROTATE THE TANK FROM LEFT TO RIGHT TO INSERT IT CORRECTLY AT THE BOTTOM OF THE COOKER.



THE TANK WILL BE IN CONTACT WITH THE HEATING PLATE (INSIDE THE RICE COOKER).



IF THE TANK IS NOT IN CONTACT WITH THE HEATING PLATE, THE RICE COOKER WILL NOT WORK OR IT MAY BE DAMAGED

For softer rice, mix the rice with water in the inner container and allow to soak for 10 minutes before cooking.

Notes : When the rice is cooked, the cooker selector will be positioned automatically on "Keep warm" function.

After cooking, let the rice stand for at least 5 minutes without removing the cover. This will ensure perfect cooking.

Brown rice takes longer to cook and we recommend adding the 2/3 of a measure of water to suit the cooking time.

Advice for quick cleaning

Put half a measure of water and a little liquid dishwashing detergent in the internal container.

Set the switch to "Cooking". and let it heat for 10 minutes.

Stop and Unplug the appliance.

Let cool.

Rinse thoroughly and dry completely before reuse.

STORAGE

-Ensure the unit is completely cool and dry.

-Do not wrap the cord around the appliance, as this will cause damage.

-Keep the appliance in a cool, dry place and out of reach from children.

GUARANTEE

Before being delivered, all our products are subjected to a rigorous control. This apparatus is guaranteed 24 months starting from the date of purchase of consumer.

The documents in proof of guarantee are :

- The invoice and
- The filled and stamped warranty plate (located on side or bottom of the gift box). Without these documents in proof, no free replacement, nor no free repair, can be carried out.

During the warranty period, we deal for free, the defects of the apparatus or the accessories, rising from a defect of materials or manufacture by repair or, replacement. The services within the framework of the guarantee do not involve any extension of the warranty period and does not give right to a new guarantee ! In the event of recourse to the guarantee, bring back the complete apparatus to your retailer, in its original packing, accompanied by the proofs of purchase.

The breakage of parts out of glass or plastic is, in all the cases, not warranted. Defects on the accessories or the wearing parts (for example: coils of engines, hooks, drive belts, remote control of replacement, teeth brushes of replacement, webs etc) as well as cleaning, maintenance or it replacement of wearing parts are not guaranteed and are thus to pay !

In the event of foreign intervention, the guarantee becomes null and void.

After flow of the warranty period, repairs can be carried out, against payment, by a specialized trade or a repair service.

SPECIFICATIONS

Power supply	220-240V~ 50/60Hz
Power	1600W
Capacity	4,2L
Norm	Class I


Made in P.R.C

The characteristics can change without prior notice.

This unit is equipped with an electrical outlet with earth and must be earthed in an according plug.

Note : In the event of question concerning the earth or electric connection, please consult a qualified personnel.

In the event of short-circuit, earthing reduces the risk of electric shock while making possible the current to be evacuated by the wire of ground.



CAUTION: In order to minimize the risks of electric shock, In the event of breakdown, not to open the case but to call upon a qualified technician for repairs.

This device complies with EC directives, it was controlled according to all current European directives, applicable such as: electromagnetic compatibility (EMC) and low voltage (LVD).

This device has been designed and manufactured in compliance with the latest regulations and technical requirements for safety.

**Imported by Sotech International
" LE PERIPOLE " N°A-107
33, Avenue du Marechal de Lattre de Tassigny
94120 Fontenay sous-bois - France**