

**ELECTRIC 3 IN 1 :  
CALLUS REMOVER + SHAVER + EPILATOR**

**Instruction manual**



Dear consumer, Please read these instructions carefully before use in order to avoid damage due to incorrect use and to better understand the functions of this product. Please pay particular attention to the safety guide.

If you pass the device on to a third party, these Operating Instructions must also be handed over.

Please keep them for future references.

## IMPORTANT SAFEGUARDS

- ❑ Please read these instructions carefully before use.
- ❑ Keep present instructions for future references.
- ❑ Check that your mains voltage corresponds to that stated on the appliance.
- ❑ Only use the appliance for domestic purposes and household or similar applications such as:
  - staff kitchen areas, in shops, offices and other working environments;
  - By clients in hotels, motels and other residential type environments;
  - Environment type like :
    - Farm Houses • Bed and Breakfast.
- ❑ Only use the appliance in the way indicated in these instructions.
- ❑ Inform potential users of these instructions.
- ❑ Never leave the appliance unsupervised when in use.
- ❑ The appliance must be used only for its intended purpose. No responsibility can be taken for any possible damage caused by incorrect use or improper handling.
- ❑ Children and persons with disabilities are not always aware of the danger posed by the use of appliances.
- ❑ This device can be used by children aged 8 years and older and adults, with reduced physical, sensory or mental capabilities or lack of experience and knowledge, if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- ❑ Cleaning and user maintenance shall not be made by children without supervision.
- ❑ This device is not a toy, do not leave small children or people with disabilities to play with.

- In order to ensure your children's safety, please keep all packaging (plastic bags, boxes, polystyrene etc.) out of their reach.
- Caution ! Do not allow small children to play with the foil :  
**THERE IS A DANGER OF SUFFOCATION !**
- Never immerse the appliance in water or any other liquid for any reason whatsoever.
- Never place it into the dishwasher.
- Never use the appliance near hot surfaces.
- Never use the appliance outside and always place it in a dry environment.
- Never use accessories, which are not recommended by the producer. They could constitute a danger to the user and risk to damage the appliance.
- Make sure the appliance has cooled down before cleaning and storing it.
- This appliance is not intended to be operated by means of an external timer or separate remote-control system.  
Always place the unit on a flat surface. Ensure, also, not to cover the device and not to put anything on it.
- Incorrect operation and improper use can damage the appliance and cause injury to the user.
- This device, designed for home use, complies with standards relating to this type of product.
- The item is not to be used, if it has been dropped or if there are visible signs of damage.
- The appliance is only to be used with the power supply unit provided with the appliance.
- The appliance must only be supplied at safety extra low voltage corresponding to the marking on the appliance.
- This appliance is only intended for household use.
- Regarding the instructions for cleaning, please refer to the below paragraph of the manual.

- This appliance is only intended for household use.

## GENERAL INFORMATION

The symbol "OPEN BOOK" means a recommendation to read important things contained in the record.



The symbol "BIN" crossed out, abbreviation WEEE (Waste of Electrical and Electronic Equipment) means that at the end of life, it should not be discarded with household waste, but filed to the sorting of the locality. Waste recovery can help preserve our environment.





The symbol "CE" is the guarantee of compliance with harmonized European standards, voluntary, reflecting the essential requirements into technical specifications. These standards are not mandatory but are guarantees of compliance with essential requirements.

The symbol ROHS (Restriction of use of some Hazardous Substances) on the Environmental Protection, certifies that for each of the five hazardous substances • Lead • Mercury • (hexavalent) chromium • products for protection against flames PBB and PBDE, the peak concentration is equal to or less than 0.1% of the weight of homogeneous material, and 0.01% for the 6th • cadmium.



The symbol "DOUBLE SQUARE" means a double insulated. A basic insulation and supplementary insulation. This device requires no connection to the mass of a protective conductor grounded. The materials are said : double insulation class II.





The symbol "III" means that the equipment concerned is designed to be supplied at a voltage of not more than 50 volts AC or 120 volts DC. Materials with this sign are classified as Class III.

The symbol "TRIMAN" indicates that the consumer is invited to dispose the product as part of a separate collection (eg recycling bin, waste, voluntary intake point).



For more information : <http://www.quefairedemesdechets.fr>

## BEFORE USE

The product only can be used as a device by rechargeable battery-powered and cordless only. It cannot be used with the power directly from the mains.

### LOCATION

1. Exfoliating head
2. Head Release button
3. Soft Handle
4. LED light
5. Power switch On / Off
6. Battery compartment
  
7. Extra shaving head
8. Extra epilator head



### CHARGING

Turn off the device by pushing the switch down.

Plug the AC adapter to the port in the device and then to a wall socket.

Charging is indicated by a red light. Battery charging time is approximately 8h. when charging is completed, disconnect the power cable from the wall socket

NOTE: The indicator light does not go off when charging is completed.  
When charging is completed, disconnect the power cable from the wall socket and from the device port.

The device is ready to use.

Charging the battery for longer than 12 hours shortens its lifespan.

If the device is not used for a long time, it is recommended to charge the battery at least once per every six months.

If the battery is not charged for the period longer than six months, its lifespan also gets shortened.

### Using 3 in 1 Beauty Set

After selecting the desired head and placing it properly on the main unit, always follow this three steps :

1. Remove the protective cap.
2. Turn the product on by pushing the switch up.
3. The product enables you to choose from 3 different functions listed below :
  1. Removing callus head
  2. Epilating head
  3. Shaving & trimming head

#### CALLUS REMOVER

The first head of this product is designed to remove coarse & Callused skin from feet & heels.

Do not use anywhere else on the body.

Do not use on broken or bleeding skin.



Wash and dry the skin that is to be treated. Remove the cap of the item.

Turn on the unit. The LED light comes on.

Touch the area with the exfoliating head.


Press gently at first then apply more pressure as you feel comfortable.

NOTE : If you press too hard, the unit will stop spinning.

Move back & forth or side to side (around 2 or 3 seconds at the same place) until callused skin is removed.

Change location and continue working for a while.

After you have reached desired results, turn the unit off by sliding the power switch downwards.



Clean the head of the unit with the brush and replace the cap over the head to protect it.

## EPILATOR & SHAVER

The second & third head of this product are designed to remove hair.

- The design of the epilator head allows rotating discs to catch even the shortest hairs and get them out by the root.
- The design of the shaver head allows blades moving back & forwards to cut even the shortest hairs.

1. Make sure the skin, to be treated, is clean, entirely dry and free from any grease or cream.
2. Do not use any cream before waxing.
3. Hair removal is easier and more comfortable immediately after taking a bath or shower. However, ensure that the skin, to be treated, is completely dry before you start waxing.

Choose the desired head and install it.

**NOTE :** If it the first time using epilator or shaver it is advised to try it out on an area with only light hair growth to get familiar to the epilation or shaving process. It is the best to epilate or shave before going to bed at night, as skin irritation usually disappears overnight.

Epilation is easier and more comfortable when the hair has the optimum length of 3–4 mm. If the hairs are longer, we recommend that you rather trim it first.

Use the shaver head to cut hair on your bikini line.

Trimmer can also be used to pre-trim long hairs (longer than 10 mm) on the underarms or bikini line.

Turn on the unit. The LED light comes on.

Touch the area with the epilating or shaving head.

Stretch the skin with your free hand to straighten the hair.

Place the appliance perpendicularly onto the skin.

(The On / Off switch pointing in the direction in which you move the appliance)

Move the unit slowly over the skin, against the direction of hair growth.

After you have reached desired results, turn the unit off by sliding the power switch downwards.

Clean the head of the unit with the brush and replace the cap over the head to protect it.

4. After hair removal, apply a moisturizing cream or lotion to help reduce possible skin irritation.

## CHANGING THE FUNCTION HEAD



Push the release button on the side and pull off the head.  
Take the desired head and place it back on the main unit. (The head is set properly when you hear “click” sound.)

## **CLEANING AND MAINTENANCE**

Before cleaning, Always switch off the appliance.

Clean the outside of the apparatus with a sponge or slightly wet linen.

Never plunge the apparatus in water or all other liquid !

Do not use abrasive cleaners, gritting, or metal brush or another cutting object.

Clean the exfoliating or shaving or epilating head after every treatment to maximize performance.

You may rinse the head under water by turning on the unit for about 10 seconds.

NOTE: The head product is water resistant, but not waterproof. Avoid submerging completely in liquid.

Once clean, dry the head, place it on the unit, Dry it completely and place the cap.

## **STORAGE**

-Ensure the unit is completely cool and dry.

-Keep the appliance in a cool, dry place and out of reach from children.

## **GUARANTEE**

Before being delivered, all our products are subjected to a rigorous control.

This apparatus is guaranteed 24 months starting from the date of purchase of consumer.

The documents in proof of guarantee are :

- The invoice and
- The filled and stamped warrantee plate (located on side or bottom of the gift box). Without these documents in proof, no free replacement, nor no free repair, can be carried out.

During the warranty period, we deal for free, the defects of the apparatus or the accessories, rising from a defect of materials or manufacture by repair or, replacement. The services within the framework of the guarantee do not involve any extension of the warranty period and does not give right to a new guarantee ! In the event of recourse to the guarantee, bring back the complete apparatus to your retailer, in its original packing, accompanied by the proofs of purchase.

The breakage of parts out of glass or plastic is, in all the cases, not warranted.

Defects on the accessories or the wearing parts (for example: coals of engines, hooks, drive belts, remote control of replacement, teeth brushes of replacement, webs etc) as well as cleaning, maintenance or it replacement of wearing parts are not guaranteed and are thus to pay !

In the event of foreign intervention, the guarantee becomes null and void.  
After flow of the warranty period, repairs can be carried out, against payment, by a specialized trade or a repair service.

## **SPECIFICATIONS**

Power supply	2 X Ni-Mh /600mAh LR06 OR AA batteries
Norm	Class III
Charging time	8H
Power	3W

Made in PRC

*The characteristics can change without preliminary preventing*

This device complies with EC directives, it was controlled according to all current European directives.

This device has been designed and manufactured in compliance with the latest regulations and technical requirements for safety.

## **ENVIRONMENTAL PROTECTION**

(Destruction of batteries)

To remove the batteries:

- Open the battery compartment and retrieve the batteries.
- THE BATTERIES MUST BE REMOVED BEFORE THE UNIT IS GIVEN TO REBUS.
- THE BATTERIES MUST BE ELIMINATED IN A SAFE WAY.
- DO NOT THROW IN A TRASH CAN, BUT GIVE IN CENTRE OF WASTE.

**Imported by Sotech International  
" LE PERIPOLE " N°C111 à 115  
33, Avenue du Marechal de Lattre de Tassigny  
94120 Fontenay sous bois - France**