

## FACIAL AND NASAL SAUNA WITH TOURMALINE COATING \* INSTRUCTION MANUAL

Dear consumer, Please read these instructions carefully before use in order to avoid damage due to incorrect use and to better understand the functions of this product. Please pay particular attention to the safety guide.

If you pass the device on to a third party, these Operating Instructions must also be handed over.

Please keep them for future references.



## IMPORTANT SAFEGUARDS

- Please read these instructions carefully before use.
- Keep present instructions for future references.
- Check that your mains voltage corresponds to that stated on the appliance.
- Only use the appliance for domestic purposes and household or similar applications such as:
  - staff kitchen areas, in shops, offices and other working environments;
  - by clients in hotels, motels and other residential type environments;
  - Environment type like :
    - Farm Houses • Bed and Breakfast.
- Only use the appliance in the way indicated in these instructions.
- When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliances switched off
- For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.
- **WARNING:** Never use this unit near bathtub, shower, wash-hand basins or other containers with water.
- Never use this apparatus near water projections.
- Never use this apparatus with the wet hands.
- If, unfortunately the apparatus is wet, immediately withdraw the cord of the socket-outlet.
- Inform potential users of these instructions.
- Never leave the appliance unsupervised when in use.

- ❑ The appliance must be used only for its intended purpose. No responsibility can be taken for any possible damage caused by incorrect use or improper handling.
- ❑ Children and persons with disabilities are not always aware of the danger posed by the use of appliances.
- ❑ This device can be used by children aged 8 years and older and adults, with reduced physical, sensory or mental capabilities or lack of experience and knowledge, if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- ❑ Cleaning and maintenance must not be made by children without supervision.
- ❑ After use, the appliance shall be cleaned to avoid the accumulation of grease and other residues.
- ❑ Children shall not play with the appliance.
- ❑ Keep the appliance and its cord out of reach of children aged less than 8 years of age when it is energized or cooling down.
- ❑ In order to ensure your children's safety, please keep all packaging (plastic bags, boxes, polystyrene etc.) out of their reach.
- ❑ Caution! Do not allow small children to play with the foil:

### **THERE IS A DANGER OF SUFFOCATION!**

- ❑ From time to time check the cord for damages. Never use the appliance if cord or appliance shows any signs of damage.
- ❑ Never immerse the appliance in water or any other liquid for any reason whatsoever.
- ❑ Never place it into the dishwasher.
- ❑ Never use the appliance near hot surfaces.
- ❑ Do not operate the appliance with a damaged cord or plug, or after the appliance has been damaged in any manner.

- ❑ If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.
- ❑ Disconnect the power source cable before any operation of cleaning of maintenance and accessories assembly.
- ❑ Never use the appliance outside and always place it in a dry environment.
- ❑ Never use accessories, which are not recommended by the producer. They could constitute a danger to the user and risk to damage the appliance.
- ❑ Never use any other connector than the one provided.
- ❑ Never move the appliance by pulling the cord. Make sure the cord cannot get caught in any way.
- ❑ Never wind the cord around the appliance and do not bend it
- ❑ Ensure that the power cord does not come into contact with hot parts of this unit.
- ❑ Make sure the appliance has cooled down before cleaning and storing it.
- ❑ The temperature of accessible surfaces may be very high when the appliance is operating. Never touch these parts, of apparatus, to avoid burning itself.
- ❑ Make sure the appliance never comes into contact with flammable materials, such as curtains, cloth, etc...& the power cord and plug do not come in contact with water.
- ❑ Before cleaning, always unplug the appliance from the power supply and let it cool down.
- ❑ This appliance is not intended to be operated by means of an external timer or separate remote-control system.
- ❑ Always place the unit on a flat surface. Ensure, also, not to cover the device and not to put anything on it.
- ❑ Always remove the plug from the wall socket when the appliance is not in use.

- When using an extension lead always make sure that the entire cable is unwound from the reel. Use solely CE approved extension leads. Input power must be at least 16A, 250V, 3000W.
- Incorrect operation and improper use can damage the appliance and cause injury to the user.
- This device, designed for home use, complies with standards relating to this type of product.
- The appliance must be used and rested on a table or flat & stable surface.

The item must not be left unattended when it is connected to main supply.

The item is not to be used, if it has been dropped or if there are visible signs of damage or if it is leaking.

This appliance is only intended for household use.

## **GENERAL INFORMATION**

The symbol "OPEN BOOK" means a recommendation to read important things contained in the record.

The symbol "BIN" crossed out, abbreviation WEEE (Waste of Electrical and Electronic Equipment) means that at the end of life, it should not be discarded with household waste, but filed to the sorting of the locality. Waste recovery can help preserve our environment.

The symbol "CE" is the guarantee of compliance with harmonized European standards, voluntary, reflecting the essential requirements into technical specifications. These standards are not mandatory but are guarantees of compliance with essential requirements.

The symbol ROHS (Restriction of use of some Hazardous Substances) on the Environmental Protection, certifies that for each of the five hazardous substances • Lead • Mercury • (hexavalent) chromium • products for protection against flames PBB and PBDE, the peak concentration is equal to or less than 0.1% of the weight of homogeneous material, and 0.01% for the 6th • cadmium.

The symbol "DOUBLE SQUARE" means a double insulated. A basic insulation and supplementary insulation. This device requires no connection to the mass of a protective conductor grounded. The materials are said : double insulation class II.

The symbol "TUB / SHOWER" crossed out means to never use the unit in a bathroom, a shower in or near water spray. (IP20 Minimum distance 3M.)

The symbol "TRIMAN" indicates that the consumer is invited to dispose the product as part of a separate collection (eg recycling bin, waste, voluntary intake point).

For more information : <http://www.quefairedemesdechets.fr>

### TO KNOW THE APPLIANCE



### **not recommended Usage**

1. Analgesics and tranquillizers should not be taken by users when using the Facial Sauna. They increase sensitivity to heat. It is advisable not to use steam care after taking these medicines.
3. We suggest cardiac people not to use steam care.
4. Do not use steam care for the following pathologies: Acne Rosacea, Rash, Psoriasis, etc.
5. It is recommended not to use the Facial Sauna for adults with physiological problems or during pregnancy.

### **TOURMALINE**

How, tourmaline coating produces beneficial effects on human body: Tourmaline produces negative ions.

Positive ions (and the lack of negative ions) are associated with the creation of stress.

Pollution, cigarette smoke, pesticides, dust, waves emitted by high voltage lines, computers, mobile phones, electrical appliances etc.

Positive ions create free radicals known to be harmful to our health.

Tourmaline converts humidity in the air into negative ions which neutralizes the free radicals created by positive ions.

In Lithotherapy, the negative ions actions on our health are the following:

- revitalization of cellular metabolism
- strengthening the immune system
- stabilization of blood pressure
- improvement of the blood circulation (dilation of the vessels)
- bone strengthening
- purification of blood (increase in alkalinity)
- facilitation of breathing
- reduction in pulse rate

- Improved cardiac function ...

Without going so far, Tourmaline is useful for the relaxation of body and mind. It helps to reduce stress and improve blood circulation.

NOTE: Have you ever noticed how one feels invigorated and in good shape, at the foot of a waterfall, near a natural spring water, walking on a beach or in the woods after a good rain?

This state of well-being is entirely due to the abundant concentration of negative ions present in nature!

The negative ions produced by Tourmaline have exactly the same positive effects on the body.

### **Using time of the product according to skin type**

The duration of steam care in accordance with of the different characteristics of the user's skin, Please, refer & do not exceed the following time.

Sensitive skin : Not more than 10 minutes each time.

Oily skin : From 10 to 15 minutes each time.

Dry skin : Not more than 8 to 10 minutes each time.

Note: Never use the steam care (facial sauna) more than 20 minutes each time; recommended time of weekly steam care does not exceed 2-3 times.

### **Before use**

Do not plug the power cord before the unit is prepared & ready.

Make sure the product is completely dry before using.

Pour 45 / 50ml of water in the measuring cup and pour the water into the pot.

Make sure the water not exceed "MAX" on the scale of the pot.

Fit the unit with facial mask or nasal mask.

Wash your face with water and soap, and when the face is clean, rinsed and dry, it was proposed that a small amount of moisture cream can be painted on facial skin.

### **FIRST USE**

Before first use, remove the unit and all accessories carefully.

Clean with soap and water, all accessories and parts in contact with skin. Clean the outside and inside of the machine cabinet with a damp sponge. Rinse and wipe dry.

### **USE**

1. Plug the unit

2. Turn the steam selector, Power indicator light up.  
For mild steam volume, select 1  
For strong steam, choose 2.
3. Steam is available around 3 minutes.

NOTE: Ionic function is, automatically, on.

#### **After use**

4. when the steam completely evaporated or If you intend to stop the steam, switch the selector to 0.
  5. Unplug the power outlet.
- NOTE: Ionic function is, automatically, off.

### **Face Care**

Mask will be steamed right on in the main assembly.

Ergonomic design is so that the shape of the mask match with Facial contour.

Close the eyes, Put the face close to the edge of the mask,

turn the valve to the left to make steam focus on the concentration of the face,

turn the valve to the right to make steam spread to the masks

Relax for 5 minutes after steam care, and then, clean the face with cold water.

Applying favourite skin-care products.

### **Nasal Care**

Make sure the nasal mask right in the main assembly.

Ergonomic design is so that the shape of the mask match with triangle nose contour.

Put the triangle face to the edge of nasal mask, so that steam will full steam into the face triangle.

Relax yourself for 5 minutes, make the moisturizing cream infiltration your skin, and then clean your face with cold water.

Applying your favourite skin-care products.

### **Operation with fragrant vanilla or herbal medicine**

Remove the facial mask

Put cotton with drops of essential oils (vanilla or else) or Chinese herbal medicine on the valve.

Apply the mask on the base

Use as normal use of facial care.

### **CLEANING AND MAINTENANCE**

Before cleaning, always: switch off the appliance, disconnect the apparatus and let it cool.

Clean the outside of the apparatus with a sponge or slightly wet linen.

Never plunge the apparatus in water or all other liquid!

Do not use abrasive cleaners, gritting, or metal brush or another cutting object.

### **STORAGE**

Ensure the unit is completely cool and dry.

Do not wrap the cord around the appliance, as this will cause damage.

Keep the appliance in a cool, dry place and out of reach from children.

### **GUARANTEE**

Before being delivered, all our products are subjected to a rigorous control.

This apparatus is guaranteed 24 months starting from the date of purchase of consumer.

The documents in proof of guarantee are:

- The invoice and
- The filled and stamped warrantee plate (located on side or bottom of the gift box). Without these documents in proof, no free replacement, nor no free repair, can be carried out.

During the warranty period, we deal for free, the defects of the apparatus or the accessories, rising from a defect of materials or manufacture by repair or, replacement. The services within the framework of the guarantee do not involve any extension of the warranty period and does not give right to a new guarantee! In the event of recourse to the guarantee, bring back the complete apparatus to your retailer, in its original packing, accompanied by the proofs of purchase.

The breakage of parts out of glass or plastic is, in all the cases, not warranted. Defects on the accessories or the wearing parts (for example: coals of engines, hooks, drive belts, remote control of replacement, teeth brushes of replacement, webs etc) as well as cleaning, maintenance or it replacement of wearing parts are not guaranteed and are thus to pay!

In the event of foreign intervention, the guarantee becomes null and void.

After flow of the warranty period, repairs can be carried out, against payment, by a specialized trade or a repair service.

### **SPECIFICATIONS**

Power supply 220-240V~ 50/60Hz

Power 100W

Norm Class II

Made in PRC

*The characteristics can change without preliminary preventing*

Ionic function    Ionic function will purify & clean air of facial sauna. This function, with the produced negative ions, is against tiredness and stimulates blood micro circulation.

CAUTION: In order to minimize the risks of electric shock, In the event of breakdown, not to open the case but to call upon a qualified technician for repairs. This apparatus satisfied EC directives, it was controlled according to all the European current directives, like: electromagnetic compatibility (EMC) and low tension (LVD).

This apparatus was designed and manufactured in respect of the last safety regulations and technical specifications.

Imported by **Sotech International**  
**N°107 - PARC "LE PERIPOLE"**  
**33, Avenue du Marechal de Lattre de Tassigny**  
**94120 FONTENAY SOUS BOIS - FRANCE**